



iMcV-T1/E1/J1 Repeater

Operation Manual



FCC Radio Frequency Interference Statement

This equipment has been tested and found to comply with the limits for a Class A computing device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which the user will be required to correct the interference at his own expense.

Any changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.

The use of non-shielded I/O cables may not guarantee compliance with FCC RFI limits. This digital apparatus does not exceed the Class A limits for radio noise emission from digital apparatus set out in the Radio Interference Regulation of the Canadian Department of Communications.

Le présent appareil numérique n'émet pas de bruits radioélectriques dépassant les limites applicables aux appareils numériques de classe A prescrites dans le Règlement sur le brouillage radioélectrique publié par le ministère des Communications du Canada.

Warranty

IMC Networks warrants to the original end-user purchaser that this product, EXCLUSIVE OF SOFTWARE, shall be free from defects in materials and workmanship under normal and proper use in accordance with IMC Networks' instructions and directions for a period of six (6) years after the original date of purchase. This warranty is subject to the limitations set forth below.

At its option, IMC Networks will repair or replace at no charge the product which proves to be defective within such warranty period. This limited warranty shall not apply if the IMC Networks product has been damaged by unreasonable use, accident, negligence, service or modification by anyone other than an authorized IMC Networks Service Technician or by any other causes unrelated to defective materials or workmanship. Any replaced or repaired products or parts carry a ninety (90) day warranty or the remainder of the initial warranty period, whichever is longer.

To receive in-warranty service, the defective product must be received at IMC Networks no later than the end of the warranty period. The product must be accompanied by proof of purchase, satisfactory to IMC Networks, denoting product serial number and purchase date, a written description of the defect and a Return Merchandise Authorization (RMA) number issued by IMC Networks. No products will be accepted by IMC Networks which do not have an RMA number. For an RMA number, contact IMC Networks at PHONE: (800) 624-1070 (in the U.S and Canada) or (949) 465-3000 or FAX: (949) 465-3020. The end-user shall return the defective product to IMC Networks, freight, customs and handling charges prepaid. End-user agrees to accept all liability for loss of or damages to the returned product during shipment. IMC Networks shall repair or replace the returned product, at its option, and return the repaired or new product to the end-user, freight prepaid, via method to be determined by IMC Networks. IMC Networks shall not be liable for any costs of procurement of substitute goods, loss of profits, or any incidental, consequential, and/or special damages of any kind resulting from a breach of any applicable express or implied warranty, breach of any obligation arising from breach of warranty, or otherwise with respect to the manufacture and sale of any IMC Networks product, whether or not IMC Networks has been advised of the possibility of such loss or damage.

EXCEPT FOR THE EXPRESS WARRANTY SET FORTH ABOVE, IMC NETWORKS MAKES NO OTHER WARRANTIES, WHETHER EXPRESS OR IMPLIED, WITH RESPECT TO THIS IMC NETWORKS PRODUCT, INCLUDING WITHOUT LIMITATION ANY SOFTWARE ASSOCIATED OR INCLUDED. IMC NETWORKS SHALL DISREGARD AND NOT BE BOUND BY ANY REPRESENTATIONS OR WARRANTIES MADE BY ANY OTHER PERSON, INCLUDING EMPLOYEES, DISTRIBUTORS, RESELLERS OR DEALERS OF IMC NETWORKS, WHICH ARE

INCONSISTENT WITH THE WARRANTY SET FORTH ABOVE. ALL IMPLIED WARRANTIES INCLUDING THOSE OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY LIMITED TO THE DURATION OF THE EXPRESS WARRANTY STATED ABOVE.

Every reasonable effort has been made to ensure that IMC Networks product manuals and promotional materials accurately describe IMC Networks product specifications and capabilities at the time of publication. However, because of ongoing improvements and updating of IMC Networks products, IMC Networks cannot guarantee the accuracy of printed materials after the date of publication and disclaims liability for changes, errors or omissions.

Table of Contents

FCC Radio Frequency Interference Statement	ii
Warranty.....	ii
About the iMcV-T1/E1/J1 Repeater.....	4
Installation	4
Configuration	5
Prerequisites	5
Description of DIP Switch-Selectable Options	7
Module LED Functions.....	12
Testing.....	13
Fiber Optic Specifications.....	16
RJ-48 Pinout	16
Specifications.....	17
IMC Networks Technical Support.....	17
Fiber Optic Cleaning Guidelines.....	18
Electrostatic Discharge Precautions.....	18
Safety Certifications.....	19

About the iMcV-T1/E1/J1 Repeater

The iMcV-T1/E1/J1 Repeater chassis mounted media conversion module allows the end user to extend the distances between T1, J1, and E1 copper telephony systems by adding a fiber segment. The distances can support up to 100km depending on the module used and the fiber type available.

Installation

At the central location the iMcV-T1/E1/J1 Repeater unit is typically installed in a managed chassis such as the iMediaChassis or the MediaChassis series.

NOTES
Chassis are also available in Industrial Ethernet (IE) configurations.
It is not recommended that the iMcV-T1/E1/J1 module be installed in an 850-33100. The power source in this chassis is not isolated, and cannot support positive reference ground systems typically used in Telco environments.
The MediaChassis/2-DC and the iMediaChassis/6-DC are suitable alternatives.

Each module requires one slot in the chassis. To install a module, remove the blank brackets covering the slots where the module is to be installed (if present) by removing the screws on the outside edges of the bracket. Slide the module into the chassis, via the card guides, until the module is seated securely in the connector. Secure the module to the chassis by tightening the captive screw. Save any “blanks” removed during installation for future use should the configuration requirements change.

Crossover/Straight-Through Connection

iMcV-T1/E1/J1 Repeater comes with an RJ-48 UTP connector that features a push-button switch, located next to the port, for selecting a crossover or straight-through connection. To select a cross-over connection, press the push-button IN. A straight-through connection is selected when the push-button is OUT. When unsure what type of connection is needed, set the push button to the position that turns the NO LNK LED off.

Configuration

The iMcV-T1/E1/J1 Repeater module is factory-configured to use the following default features:

T1/E1 Mode	T1
Receive Equalizer Gain Limit (EGL)	-30 dB (Limited Long Haul)
Line Encoding	AMI (Passive Mode)
Transmit LIU Waveshape (Build-out)	DSX-1 (0 to 133 ft) 0 dB CSU
Receive LIU Termination	Receive Side 100 ohms Enabled
Transmit Data Source	Standard Data
Jitter Attenuator Select	Place Jitter Attenuator on TX Side
Remote Management	Remote Management Disabled
Loopback Selection	No Loopback
Monitor/Boost Mode	No Boost
NRZ Selection	Disable NRZ (Passive Mode)

The iView² management software can be used to change some of the iMcV-T1/E1/J1 Repeater features after installing the modules in the chassis. Refer to the iView² online help for more information.

Passive Mode

It is recommended that the default Passive mode configuration is used for most typical applications. Passive mode allows the fiber segment to pass data unchanged between the T1/E1 segments independent of the actual line coding (AMI, B8ZS, or HDB3). All errors and fault conditions from one T1/E1 end will pass through the fiber to the other end as if there were one long T1/E1 connection.

Prerequisites

Before installing the iMcV-T1/E1/J1 Repeater modules, perform the following:

- Make sure the modules are correct for the fiber type and distance requirements.
- Make sure that T1 UTP lines **DO NOT** use simplex power (no wet lines).
- Before installing the iMcV-T1/E1/J1 Repeater modules, verify the DIP Switches are configured for the feature wanted.
- Make sure to deploy the iMcV-T1/E1/J1 Repeater modules in pairs.
- Make sure the Remote Chassis is not managed.

NOTE

The iMcV-T1/E1/J1 Repeater modules are delivered pre-configured for standard T1 operation in Passive mode. To enable remote management, the user must move DIP Switch S2-2 to the "ON" position on the Remote module (refer to the DIP Switch diagram and table).

Managed Modules

To manage iMcV-T1/E1/J1 Repeater modules, an SNMP agent must be present; the iMediaChassis requires an SNMP management module. For a managed environment, first manually configure all of the desired DIP Switch selectable features to match what will be configured through the SNMP Management Module.

Use the Graphical User Interface (GUI) to enable features by using the iView² SNMP management software. In a managed chassis, the software settings take priority over the SNMP enabled feature DIP Switch settings. Make sure that the software settings match the desired configuration requirements for the installation.

iView² Management Software

iView² is the IMC Networks management software designed specifically for the IMC Networks "iMcV" family of modules. It features a GUI and gives network managers the ability to monitor and control the manageable IMC Networks products.

iView² is available in several versions and can also function as a snap-in module for HP OpenView Network Node Manager and other third party SNMP Management software. For assistance in selecting the right version of iView² for your operating system, please visit:

<http://www.imcnetworks.com/products/iview2.cfm>

iView² supports the following platforms:

- Windows NT
- Windows 2000
- Windows XP
- Windows Vista

In addition, there are Java versions of iView² for any Java-capable operating systems such as Linux.

Please see the *SNMP Management Module* for software configuration options.

NOTE

IMC Networks' iView² software is available for downloading from the web site:
www.imcnetworks.com.

Unmanaged Modules

Before installing the iMcV-T1/E1/J1 Repeater module into an unmanaged chassis, configure the module hardware-selectable features via DIP Switches located at position S3 and S2 on the PCB (refer to the *DIP Switch Table* section for more information). The jumpers located at positions JP1 and JP2 are factory configured—DO NOT CHANGE.

Description of DIP Switch-Selectable Options

The iMcV-T1/E1/J1 Repeater module includes movable DIP Switches for hard switching the optional features. Some of these switch options are overridden by the management setting of a managed chassis (refer to the *DIP Switch Table* section for a list of the iView² managed switches).

This module is shipped in the standard T1 option configuration. The following section contains a brief description of the available options.

T1/E1/J1 Mode

This option allows the user to select the data rate standard that the module will use when converting: T1/J1 (default) or E1. The default is OFF, T1/J1 mode selected.

Receive Equalizer Gain Limit (EGL)

This option allows the user to compensate for diminishing signal intensity over the data line by adjusting the sensitivity of the UTP receiver. By setting the Receive Equalizer Gain Limit, very long copper lines can be utilized.

Line Encoding

This option allows the user to set the transmit/receive encoding for HDB3, B8ZS or AMI (default).

NOTE
There are currently no applications that use any other settings than AMI encoding and NRZ disabled (Passive mode). Changing the encoding setting to anything other than AMI can result in data corruption.

Transmit LIU Waveshape (Line Build-out)

This option allows the user to control the waveshape being output by the transmitter. This helps to correct problems related to long cables. Improperly setting this switch will cause signal degradation.

Receive LIU Termination (Line Termination)

This option allows the user to set the receive termination. This is used to properly terminate cables in order to prevent signal reflections which can cause signal degradation.

Transmit Data Source

This option allows the user to set the module to send normal data (default) or to send specific test-patterns of data to determine problems along the cable as a diagnostic tool. The user can set the module to send a PRBS ($2^{15}-1$ for E1 and $2^{20}-1$ for T1), an alternating ones and zeros, or an unframed all ones code, depending on the diagnostic requirements.

Jitter Attenuator Select

This option allows the user to select Jitter Attenuation on the UTP transmit or receive side. This decreases jitter in the data stream which increases data reliability.

NOTE
The jitter attenuator must always be enabled on the transmit side of the copper line.

Loopback Selection

This option allows the user to set the Loopback location on the module. Loopback is a diagnostic tool that enables the user to test the integrity of the line by allowing the data to be looped back. The following independent loopback locations are included on the module:

- Analog Loopback** Set this switch on the Remote module to loop the data back from the remote copper port (refer to the *Remote Copper Loopback Mode* section for more information).
- Local Loopback** Set this switch on the Remote module to loop the data back from the remote fiber port (refer to the *Remote Fiber Loopback Mode* section for more information).
- Remote Loopback** Set this switch on the local module to loop the data back from the local fiber port (refer to the *Local Fiber Loopback Mode* section for more information).

Refer to the *Loopback Testing* section for application examples of the loopback testing modes.

Remote Management

This option allows the user to enable Remote management on the module. **The remote management feature is designed to work only on the remote module of the Local/Remote pair.** With Remote management enabled, the user can easily perform the following:

- Test the line integrity of the remote copper port.
- Use the Local unit to configure all SNMP-configurable features for both units.
- Use the Local unit to download firmware for both units.

Refer to the *Module LED Functions* section for more information.

NOTE
When the user enables the Remote management feature on the remote module, it is necessary to disable SNMP-management on the chassis in which the remote unit is installed (i.e. turn the iMediaChassis enter chassis SNMP switch off, or do not install an SNMP Management module in either an iMediaChassis or iMcV series chassis.

Monitor/Boost Mode

This option allows the user to boost the UTP receive signal (i.e internal linear gain boost). This helps the UTP receiver to compensate for line loss.

NRZ (Non-Return-to-Zero)

This option allows the user to enable or disable the NRZ mode.

NOTE
There are currently no applications that use any other settings than AMI encoding and NRZ disabled (Passive mode). Enabling NRZ can result in data corruption.


Enabling NRZ terminates the line coding on the copper line. This forces the module to send raw data to the fiber line without line code information.

Switch Settings for Switch S2					
SWITCH S2	T1/E1 Selection				
	S2-1: OFF	T1 Mode Selected			default
	S2-1: ON	E1 Mode Selected			
	Receive Equalizer Gain Limit (EGL)				
	E1				<i>iVIEW²</i>
	S2-2: ON	-12 dB (Short Haul)			<i>iVIEW²</i>
	S2-2: OFF	-43 dB (Long Haul)			<i>iVIEW²</i>
	T1				<i>iVIEW²</i>
	S2-2: ON	-36 dB (Long Haul)			<i>iVIEW²</i>
	S2-2: OFF	-30 dB (Limited Long Haul)			<i>iVIEW²</i> default
	Line Encoding <i>iVIEW²</i>				<i>iVIEW²</i>
	S2-3: ON	HDB3 (E1) / B8ZS (T1)			<i>iVIEW²</i>
	S2-3: OFF	AMI (Required for Passive Mode)			<i>iVIEW²</i> default
	Transmit LIU Waveshape (Build-out)				
	E1				
	S2-4: ON	S2-5: ON	S2-6: ON	75 ohms	
	S2-4: OFF	S2-5: ON	S2-6: ON	125 ohms	
	S2-4: ON	S2-5: ON	S2-6: OFF	75 S ohms w/ High Return Loss	
	S2-4: OFF	S2-5: ON	S2-6: OFF	125 S ohms w/ High Return Loss	
	T1				
	S2-4: ON	S2-5: ON	S2-6: ON	DSX-1 (0 to 133 ft) 0 dB CSU	
	S2-4: OFF	S2-5: ON	S2-6: ON	DSX-1 (133 to 266 ft)	
	S2-4: ON	S2-5: OFF	S2-6: ON	DSX-1 (266 to 399 ft)	
	S2-4: OFF	S2-5: OFF	S2-6: ON	DSX-1 (399 to 533 ft)	
	S2-4: ON	S2-5: ON	S2-6: OFF	DSX-1 (533 to 655 ft)	
	S2-4: OFF	S2-5: ON	S2-6: OFF	-7.5 dB CSU	
	S2-4: ON	S2-5: OFF	S2-6: OFF	-15 dB CSU	
	S2-4: OFF	S2-5: OFF	S2-6: OFF	-22.5 dB CSU	
	Receive LIU Termination				
	S2-7: ON	S2-8: ON	Receive Side Termination Disabled		
S2-7: OFF	S2-8: ON	Receive Side 120 ohms Enabled			
S2-7: ON	S2-8: OFF	Receive Side 100 ohms Enabled			
S2-7: OFF	S2-8: OFF	Receive Side 75 ohms Enabled			
Transmit Data Source <i>iVIEW²</i>					
S2-9: ON	S2-10: ON	Standard Data		<i>iVIEW²</i> default	
S2-9: OFF	S2-10: ON	Transmit Pseudorandom Bit Sequence (PRBS)		<i>iVIEW²</i>	
S2-9: ON	S2-10: OFF	Transmit Alternating Ones and Zeros		<i>iVIEW²</i>	
S2-9: OFF	S2-10: OFF	Transmit Unframed All Ones		<i>iVIEW²</i>	

Switch Settings for Switch S3					
SWITCH S3	Jitter Attenuator Select				
	S3-1: ON	Place Jitter Attenuator on RCV Side			
	S3-1: OFF	Place Jitter Attenuator on XMT Side			default
	Remote Management				
	S3-2: ON	Remote Management Enabled (only at the REMOTE end)			
	S3-2: OFF	Remote Management Disabled (only at the LOCAL end)			default
	Loopback Selection <i>iVIEW</i>²				
	S3-3: ON	S3-4: ON	None		<i>iVIEW</i> ² default
	S3-3: OFF	S3-4: ON	Local Loopback		<i>iVIEW</i> ²
	S3-3: ON	S3-4: OFF	Analog Loopback		<i>iVIEW</i> ²
	S3-3: OFF	S3-4: OFF	Remote Loopback		<i>iVIEW</i> ²
	Monitor/Boost Mode				
	S3-5: ON	S3-6: ON	Normal Operation (No Boost)		default
	S3-5: OFF	S3-6: ON	20 dB		
	S3-5: ON	S3-6: OFF	26 dB		
S3-5: OFF	S3-6: OFF	32 dB			
NRZ Selection <i>iVIEW</i>²					
S3-7: ON	Disable NRZ (Required for Passive Mode)			<i>iVIEW</i> ² default	
S3-7: OFF	Enable NRZ (Line Terminating Mode)			<i>iVIEW</i> ²	
Fiber Type					
<i>S3-8: Factory Configured</i>		<i>DO NOT CHANGE</i>			
<i>S3-9: Factory Configured</i>		<i>DO NOT CHANGE</i>			
<i>S3-10: Factory Configured</i>		<i>DO NOT CHANGE</i>			

DIP Switch Table

All *iView*² enabled switches are overridden by management software.



Module LED Functions

This section describes the LEDs and their functions. The Fiber port LED RM is the only LED that should be lit on the modules under normal operating conditions.

Copper Port LEDs

- LPBK Glows green when the module is set to one of the Loopback modes.
- NO LNK Glows green when a UTP link is **NOT** established.
- PBEO Only used when the **Transmit Data Source** option is set to PRBS. This LED will glow amber when the iMcV-T1/E1/J1 Repeater module receives errors and will stay dark when the converter receives a PRBS without errors.

Fiber Port LEDs

- NRZ Glows green when the NRZ mode is enabled.
- RM Glows green on the Remote unit when Remote management is enabled. Glows green on the Local unit when it has discovered a Remote unit with Remote management enabled.
- NO LNK Glows green when a fiber link has **NOT** been established.
- SYM Glows amber when a 4-bit to 5-bit (4b/5b) symbol encoding error in the fiber line is detected.



Testing

To test a media converter by itself, first make sure there is an appropriate fiber patch cable, then perform the following steps:

1. Connect the media converter to the T1/E1 device with a standard UTP cable. If the **NO LNK** LED for the copper port remains on, a valid signal is not being received. Push the crossover push button on the front of the unit. Verify that the **NO LNK** LED for the copper port is off.
2. Loop a single strand of fiber from the transmit port to the receive port of the media converter. Verify that the **NO LNK** LED for the fiber port is off.

Or

For single-strand fiber products, connect a single fiber cable from the Local iMcV-T1/E1/J1 Repeater to the remote iMcV-T1/E1/J1 Repeater. Verify that the **NO LNK** LED for the fiber port is off.


Loopback Testing

The iMcV-T1/E1/J1 Repeater includes the following loopback locations:

- Local
- Remote
- Analog


Local Loopback

The Local loopback location on the module loops the fiber-receive port to the fiber-transmit port.




Remote Loopback

The Remote loopback location on the module loops the fiber-transmit port to the fiber-receive port.



Analog Loopback

The Analog loopback location on the module loops the copper-transmit port to the copper-receive port.



The iMcV-T1/E1/J1 Repeater can be configured to use the following loopback test modes:

- | | |
|------------------------------------|--------------------------------------------------------------------------------------------------------------------------------|
| Local Fiber Loopback Mode | This setting tests the path from the CO copper port to the Local iMcV-T1/E1/J1 Repeater module fiber port and back. |
| Remote Fiber Loopback Mode | This setting tests the path from the CO copper port to the Remote iMcV-T1/E1/J1 Repeater module fiber port and loops it back. |
| Remote Copper Loopback Mode | This setting tests the path from the CO copper port to the Remote iMcV-T1/E1/J1 Repeater module copper port and loops it back. |


The following illustrations show a typical progression of digital loopback tests; this series allows the user to individually test each segment of the conversion. To test the copper segment at the remote location requires the PRBS test described in the next section.

Local Fiber Loopback Mode

To set the loopback testing mode to Local Fiber Loopback Mode, perform the following:

1. Set the Local iMcV-T1/E1/J1 Repeater module to **Remote** Loopback (DIP Switch S3-3=Off and S3-4=Off)
2. Set the Remote iMcV-T1/E1/J1 Repeater module Loopback to **None** (DIP Switch S3-3=On and S3-4=On).

This configuration allows the user to test the path from the CO copper port to the Local iMcV-T1/E1/J1 Repeater module fiber port and loop it back. The transmitted data is sent unhindered and the received data is ignored.




Remote Fiber Loopback Mode

To set the loopback testing mode to Remote Fiber Loopback Mode, perform the following:

1. Set the Local iMcV-T1/E1/J1 Repeater module Loopback to **None** (DIP Switch S3-3=On and S3-4=On)
2. Set the Remote iMcV-T1/E1/J1 Repeater module to **Local** Loopback (DIP Switch S3-3=Off and S3-4=On).

This configuration allows the user to test the path from the CO copper port to the Remote iMcV-T1/E1/J1 Repeater module fiber port and loop it back. The transmitted data is sent unhindered and the received data is ignored.




Remote Copper Loopback Mode

To set the loopback testing mode to Remote Copper Loopback Mode, perform the following:

1. Set the Local iMcV-T1/E1/J1 Repeater module Loopback to **None** (DIP Switch S3-3=On and S3-4=On)
2. Set the Remote iMcV-T1/E1/J1 Repeater module to **Analog** Loopback (DIP Switch S3-3=On and S3-4=Off).

This configuration allows the user to test the path from the CO copper port to the Remote iMcV-T1/E1/J1 Repeater module copper port and loop it back. The transmitted data is sent unhindered and the received data is ignored.




After the user has confirmed the integrity of these data paths, the user can activate the PRBS data generator on the Remote module and place a loopback on the customer premise equipment to test the final copper segment (refer to the Testing with PRBS section for more information).


Testing with Pseudorandom Bit Sequence (PRBS)

To test the copper segment from the Remote module to the Customer Premises Equipment (CPE) by using PRBS, perform the following:

1. Set the CPE to loopback the signal.



2. Set the Remote module to generate PRBSs (DIP Switch S2-9=On and S2-10=Off).



Check the LEDs to verify errors are not received (refer to the Module LED Functions section for more information).


Fiber Optic Specifications

For fiber optic specifications, visit our Web site at www.imcnetworks.com.

RJ-48 Pinout

The following table lists the pin configuration for the RJ-48 connector.

Pin	Signal
1	Receive Ring
2	Receive Tip
3	No Connection
4	Transmit Ring
5	Transmit Tip
6	No Connection
7	No Connection
8	No Connection



Specifications

Power Consumption (Typical)

0.550 Amp @ 5V

Operating Temperature

+32°F to +122° F (0°C to +50° C)

Storage Temperature

-4°F to +158°F (-20°C to +70° C)

Humidity

5 to 95% (non-condensing); 0 to 10,000 ft. altitude

Dimensions

Single Slot iMcV-Module

IMC Networks Technical Support

Tel: (949) 465-3000 or (800) 624-1070 (in the U.S. and Canada);
+32-16-550880 (Europe)

Fax: (949) 465-3020

E-Mail: techsupport@imcnetworks.com

Web: www.imcnetworks.com

Fiber Optic Cleaning Guidelines

Fiber Optic transmitters and receivers are extremely susceptible to contamination by particles of dirt or dust, which can obstruct the optic path and cause performance degradation. Good system performance requires clean optics and connector ferrules.

1. Use fiber patch cords (or connectors, if you terminate your own fiber) only from a reputable supplier; low-quality components can cause many hard-to-diagnose problems in an installation.
2. Dust caps are installed at IMC Networks to ensure factory-clean optical devices. These protective caps should not be removed until the moment of connecting the fiber cable to the device. Should it be necessary to disconnect the fiber device, reinstall the protective dust caps.
3. Store spare caps in a dust-free environment such as a sealed plastic bag or box so that when reinstalled they do not introduce any contamination to the optics.
4. If you suspect that the optics have been contaminated, alternate between blasting with clean, dry, compressed air and flushing with methanol to remove particles of dirt.

Electrostatic Discharge Precautions

Electrostatic discharge (ESD) can cause damage to any product, add-in modules or stand alone units, containing electronic components. Always observe the following precautions when installing or handling these kinds of products

1. Do not remove unit from its protective packaging until ready to install.
2. Wear an ESD wrist grounding strap before handling any module or component. If the wrist strap is not available, maintain grounded contact with the system unit throughout any procedure requiring ESD protection.
3. Hold the units by the edges; do not touch the electronic components or gold connectors.
4. After removal, always place the boards on a grounded, static-free surface, ESD pad or in a proper ESD bag. Do not slide the modules or stand alone units over any surface.



WARNING! Integrated circuits and fiber optic components are extremely susceptible to electrostatic discharge damage. Do not handle these components directly unless you are a qualified service technician and use tools and techniques that conform to accepted industry practices.

Safety Certifications

UL/CUL: Listed to Safety of Information Technology Equipment, including Electrical Business Equipment.

CE: The products described herein comply with the Council Directive on Electromagnetic Compatibility (2004/108/EC) and the Council Directive on Electrical Equipment Designed for use within Certain Voltage Limits (2006/95/EC). Conforms to UL Std. 60950-1; Certified to CSA Std. C22.2 No. 60950-1



**Class 1 Laser product, Luokan 1 Laserlaite,
Laser Klasse 1, Appareil A' Laser de Classe 1**

European Directive 2002/96/EC (WEEE) requires that any equipment that bears this symbol on product or packaging must not be disposed of with unsorted municipal waste. This symbol indicates that the equipment should be disposed of separately from regular household waste. It is the consumer's responsibility to dispose of this and all equipment so marked through designated collection facilities appointed by government or local authorities. Following these steps through proper disposal and recycling will help prevent potential negative consequences to the environment and human health. For more detailed information about proper disposal, please contact local authorities, waste disposal services, or the point of purchase for this equipment.





19772 Pauling • Foothill Ranch, CA 92610-2611 USA
TEL: (949) 465-3000 • FAX: (949) 465-3020
www.imcnetworks.com

**ISO 9001:2008
REGISTERED**



© 2011 IMC Networks. All rights reserved

The information in this document is subject to change without notice. IMC Networks assumes no responsibility for any errors that may appear in this document. iMcV-T1/E1/J1 is a trademark of IMC Networks. Other brands or product names may be trademarks and are the property of their respective companies.

Document Number 50-80200-00 B2

March 2011