

## Americas

Atlanta - 678-957-9614  
Boston - 774-760-0087  
Chicago - 630-285-0071  
Cleveland - 216-447-0464  
Dallas - 972-818-7423  
Detroit - 248-538-2250  
Kokomo - 765-864-8360  
Los Angeles - 949-462-9523  
Phoenix - 480-792-7200  
Santa Clara - 408-961-6444  
Toronto - 905-673-0699

## Asia/Pacific

Australia - Sydney - 61-2-9868-6733  
China - Beijing - 86-10-8528-2100  
China - Chengdu - 86-28-8665-5511  
China - Hong Kong SAR - 852-2401-1200  
China - Nanjing - 86-25-8473-2460  
China - Qingdao - 86-532-8502-7355  
China - Shanghai - 86-21-5407-5533  
China - Shenyang - 86-24-2334-2829  
China - Shenzhen - 86-755-8203-2660  
China - Wuhan - 86-27-5980-5300  
China - Xiamen - 86-592-2388138  
China - Xian - 86-29-8833-7252  
China - Zhuhai - 86-756-3210040  
India - Bangalore - 91-80-3090-4444  
India - New Delhi - 91-11-4160-8631  
India - Pune - 91-20-2566-1512  
Japan - Yokohama - 81-45-471-6166  
Korea - Daegu - 82-53-744-4301  
Korea - Seoul - 82-2-554-7200  
Malaysia - Kuala Lumpur - 60-3-6201-9857  
Malaysia - Penang - 60-4-227-8870  
Philippines - Manila - 63-2-634-9065  
Singapore - 65-6334-8870  
Taiwan - Hsin Chu - 886-3-6578-300  
Taiwan - Kaohsiung - 886-7-536-4818  
Taiwan - Taipei - 886-2-2500-6610  
Thailand - Bangkok - 66-2-694-1351

## Europe

Austria - Weis - 43-7242-2244-39  
Denmark - Copenhagen - 45-4450-2828  
France - Paris - 33-1-69-53-63-20  
Germany - Munich - 49-89-627-144-0  
Italy - Milan - 39-0331-742611  
Netherlands - Drunen - 31-416-690399  
Spain - Madrid - 34-91-708-08-90  
UK - Wokingham - 44-118-921-5869

03/26/09

# MRF24J40MA/MB PICtail™/PICtail Plus Daughter Board

## Overview

The MRF24J40MA/MB PICtail™/PICtail Plus Daughter Board is a demonstration and development daughter board for the following modules:

- MRF24J40MA IEEE 802.15.4 2.4 GHz RF Transceiver module (AC164134-1)
- MRF24J40MB 2.4 GHz IEEE 802.15.4 20 dBm RF Transceiver module (AC164134-2)

The daughter board can plug into multiple Microchip Technology demonstration and development boards. For example, the board is appropriate for 8-bit microcontroller development using the PIC18 Explorer Board (DM183032) or for 16-bit microcontroller development using the Explorer 16 Development Board (DM240001).

## User's Guide

The **MRF24J40MA/MB PICtail/PICtail Plus Daughter Board User's Guide (DS51867)** is available for download at <http://www.microchip.com/wireless>. The User's Guide contains more detailed information on the features, operation, schematics and the PCB (Printed Circuit Board).

## Software

Sample source code is available from the Microchip Wireless Design Environment: Microchip Wireless Media Access Controller (MiMAC) and Microchip Wireless Application Programming Interface (MiApp), as described in application notes AN1283 and AN1284, respectively. A Quick Start Guide is included in the software installation package that explains the installation and operation of the demonstration program. The Quick Start Guide is available for download from the Microchip web site <http://www.microchip.com/wireless>.

## Operation

Programming and configuration options for the MRF24J40MA and MRF24J40MB transceiver modules are provided in the **MRF24J40 IEEE 802.15.4 2.4 GHz RF Transceiver Data Sheet (DS39776)**.

Sample source code is the best place to start. Refer to the compile options when enabling the MRF24J40MA and MRF24J40MB transceiver modules.

### IMPORTANT

The MRF24J40MB module contains a power amplifier (PA) and low noise amplifier (LNA). It is important that the MRF24J40 be configured to control the PA and LNA. Refer to **Section 4.2 External PA/LNA Control** in the *MRF24J40 IEEE 802.15.4 2.4 GHz RF Transceiver Data Sheet* (DS39776). When using the sample source code, refer to the compile options to enable the PA and LNA.

### CAUTION

Voltage and current to the MRF24J40MA/MB PICtail/PICtail Plus Daughter Board should be in the range of 2.4-3.6V and capable of supplying 130 mA. Ensure that the daughter board is plugged into a development/demonstration board that meets this power requirement; otherwise, damage to the MRF24J40 may occur.

## Jumper Configuration

Power Disconnect/Current Measure Jumpers (JP1/JP2) – Two, 2-pin headers are connected in parallel. A shunt connects power to the MRF24J40 module. A current meter can be placed on the header and the shunt removed to measure current consumption.

TIP: To prevent power interruption to the MRF24J40 module, keep the shunt on the header while connecting the current meter. Once connected, remove the shunt to measure current.

INT2 Jumper (JP3) – For the PIC18 Explorer Board, jumpering JP3 with a shunt allows the connection of RA5 to RB2/INT2 and enables push-button switch S2 to trigger an interrupt.



Microchip Technology Inc. • 2355 West Chandler Blvd. • Chandler, AZ 85224-6199  
[www.microchip.com](http://www.microchip.com)

The Microchip name and logo, the Microchip logo and MPLAB are registered trademarks of Microchip Technology Incorporated in the U.S.A. and other countries. PICkit is a trademark of Microchip Technology Incorporated in the U.S.A. and other countries. All other trademarks mentioned herein are property of their respective companies. © 2009, Microchip Technology Incorporated, Printed in the U.S.A. All Rights Reserved. 7/09



DS51870A